

# User Guide

## High Resolution Quantitative Cartridge Kit (C105202-Q)

### A. Specifications

Specification	Description
DNA Sizing Range	20-1,500 bp
DNA Sizing Precision*	2% CV
DNA Quantitative Precision*	4% CV
Sample Number	200 runs
Shelf Life	6 months

\* Precision is determined by the 15-622 DNA Size Marker (C109200).

### B. Kit Components and Storage Conditions

Item	Storage Condition
High Resolution Quantitative Cartridge (C105202-Q)	4-30°C (Do Not Freeze)
20-1,500 bp Quantitative Marker (C109109-500Q, 500 µL)	Short-Term (≤ 3 months): 4-30°C Long-Term (> 3 months): -20°C
15-622 bp Size Marker (C109200-100, 100 µL)	Short-Term (≤ 3 months): 4-30°C Long-Term (> 3 months): -20°C
Separation Buffer (C104406, 50 mL)	4-30°C
Dilution Buffer (C104405, 15 mL)	4-30°C
Mineral Oil (C104404, 8 mL)	4-30°C


• Please always store cartridges in a light-proof bag, and then store in the cartridge box after analysis.

### C. Cartridge Unpacking Preparation


The new cartridge must undergo HV check and calibration. Please follow the instructions provided in the unpacking guide and calibrate using C109109 Quantitative Marker.

- Calibration mix for cartridge unpacking:
  - 20 bp-1,500 bp Quantitative Marker (C109109): 5 µL
  - Dilution Buffer (C104405): 15 µL

### D. Buffer, Marker, and Sample Preparation



• Ensure the buffer tray is pushed to the end until the color bar aligns with the edge of the holder.



### 1. Compatible Sample Tubes

	Name	Cat. No.	Volume	Image
<b>Qsep<sub>100</sub> / 8-well Sample Tray</b>	0.1 mL PCR Tube	-	≥ 10 µL	
	0.2 mL PCR Tube	-	≥ 20 µL	
<b>12-well Sample Tray</b>	0.1 mL Strip Tube	C104252	≥ 10 µL	
<b>16-strip Sample Tray</b>	16-strip Sample Tube	C104254	≥ 10 µL	
<b>18-strip Sample Tray</b>	18-strip Sample Tube	C104257	≥ 10 µL	

### 2. Size Marker Mix for Different Size Ranges

- For Sample Size Range from 20 bp to 1,500 bp:
  - 20 bp-1,500 bp Quantitative Marker (C109109): 5 µL
  - 15-622 bp Size Marker (C109200): 10 µL
  - Dilution Buffer (C104405): 5 µL

### 3. Sample Mix Preparation

- Quantitative Marker (C109109/C109102): 5 µL
- Sample: X (2~15) µL
- Dilution Buffer (C104405): 15-X (0~13) µL


### 4. Recommended Sample Concentration

Fragmented sample: 0.2-50 ng/µL [Best: 0.5~5 ng/µL]


# User Guide

## High Resolution Quantitative Cartridge Kit (C105202-Q)

### E. Software Operation Guide




1. Sample Position: Place the sample and select the corresponding position. Input sample information if necessary.



- For *Qsep<sub>i</sub>* and *Qsep<sub>i</sub>-Plus* users, select the appropriate markers and proceed to step 2.

2. Method: Set (a) Analysis Type to Quantitative and input the sample volume for the sample mix. Select (b) Quantitative Marker and (c) Analytic Method in the Method Selector.



- Adjust injection conditions based on sample concentration.

Sample Concentration	High (2kV, 10s)	Regular (4kV, 10s)	Low (8kV, 10s)
Fragmented DNA	> 10 ng/μL	0.1-10 ng/μL	0.01-0.1 ng/μL

3. Sample Duration: Adjust the sample injection time to increase/decrease injection amount.

- Modify injection conditions based on sample concentration.


4. Runs: Set the repetition time.

5. Separation Duration: Adjust the duration to extend/reduce the separation time.

(Optional)

6. Result Name: Input the result name for the result file.

7. Para: Choose between (a) Reference Marker Table and (b) Create Size Marker for calculation.



- When using "Create Size Marker" function, select the appropriate size marker you use. For example, "20-1.5k" is paired with C109200.


8. Click "Run" to start the sequence analysis.

## User Guide

### High Resolution Quantitative Cartridge Kit (C105202-Q)

#### F. Result & Application

##### Quantitative Marker & Size Marker Result



#### G. Troubleshooting

Before attempting any troubleshooting, ensure that the system is functioning properly and that all operations are following the instructions.

If encountering unstable current during sample injection or separation steps, which may be caused by unknown substances in PCR reagent buffer or other kit buffers, consider the following solutions:

1. Dilute the sample using dilution buffer.
2. Centrifuge the sample for a period to allow residues to accumulate at the bottom of the tube.
3. Insert a "T-purge-120" method between several sample runs. For example, insert one run of "T-Purge-120" every 5-10 sample runs.

Sequence		Assay						
Open		Save		Save As				
SN	Sample Position	Method	Sample Duration	Runs	Separation Duration	Result Name	Para	Add
1	A-01.A...	M-4-10-06-300	10	1	300	Test 1 Sample ID		
2		T-Purge-120	0	1	0	Sample ID		
3	B-01.B...	M-4-10-06-300	10	1	300	Test 2 Sample ID		

Insert

Delete

Up

Down

02:32

#### H. Cartridge Disposal

Please wear gloves before discarding the cartridge.

##### Gel reservoir



1. Bend the cartridge tip.
2. Open the cap on the gel reservoir and remove the inner cap.
3. Pour the gel into the chemical waste container.
4. Dispose of the cartridge in the trash bin.



##### Cartridge tip

Contact Information:

Company Name: BiOptic Inc.

Address: 5F., No.108, Minquan Rd., Xindian District, New Taipei City 23141, Taiwan

Tel: +886-2-2218-8726, Fax: +886-2-2218-8727, E-mail: service@bioptic.com.tw